






Use only your voice to dial the numbers you want. First you record a name for a specific number in your Contacts, then you can dial that number by saying the voice name into your phone. This icon  appears to the left of the Contacts type icon if a voice name is assigned.

## For Most Nextel Phones:


### Adding a Voice Name to a Contact

1. From the Contacts list, scroll to the entry you want to edit.
2. Press  under **Edit**. -or-  
If **Edit** is not one of your options, press  and select **Edit**.  
The entry details screen displays.
3. Select **[Options]**.
4. Select **Voice Name**.
5. As directed by the screen prompts, say and repeat the name you want to assign to the number. Speak clearly into the microphone.
6. When you are finished, press  under **Back**.
7. Press  under **Save** to save your changes.

### Using a Voice Name to Dial

If you have created a voice name in Contacts for the number you want to call, say the voice name into your phone to enter the number.

You can use a voice name to enter a number with the flip open or closed.

1. Press and hold  until the Say Name Now screen appears.
2. Speaking into the microphone, say the voice name assigned to the number you want to call.  
Your phone plays the name back to you.
3. If you are making a phone call, the call is placed automatically.  
Note: If you are making a Direct Connect call, press and hold the PTT button to place the call.

## For the i205, i305, i530, i55sr and i58sr:

Visit <http://idenphones.motorola.com> to purchase and download the voice recognition software.